




calibSensor (main window) SaveAs Save Quit Ele 1050< 1000-1060-



INFORMATION OF MARKER







**INFORMATION OF MARKER** 

山

.









FIG. 12



20 ... 24 6 24 .




FIG. 14A




FIG. 14B





FIG. 14C









FIG. 16







1260 Rotate world coordinate X-axis Y-axis Z-axis 증 등 등 Set axis Close 会 orientation - x: 1.000000 会 orientation - y: 0.0000000 会 orientation - z: 0.000000 FIG. 19 Reset to default Rotate transmitter X-axis Y-axis Z-axis 은 은 는 World Transform Initial Transforms Dialog Euler angle azimuth (z-axis): elevation (y-axis):[ orientation - angle: [ roll (x-axis):[ position - x: 400 position - y: 400 position - z: 550 Local Transform